E-M-HW4v3-F2-021_10	Rotronic AG Bassersdorf, Switzerland
Document code	Unit
HW4 software v.3: Device Manager and Data	Instruction Manual
Logging LOG-RC Series Data Loggers	Document Type
Document title	Page 1 of 18

# HW4 Software version 3

# Device Manager and Data Logging LOG-RC Series Data Loggers

HW4 Softw Profession	are AIR AIR TECHNOLOGY	<b>FOTTFONIC</b> LEADING IN HUMIDITY MEASUREMENT
	Start HW4 Psychrometric Conversion Registration Help Exit	IS rotraic () () () () () () () () () ()
Do not display this form again	~	/ersion 3.1.0.0

E-M-HW4v3-F2-021_10	Rotronic AG Bassersdorf, Switzerland
Document code	Unit
HW4 software v.3: Device Manager and Data	Instruction Manual
Logging LOG-RC Series Data Loggers	Document Type
Document title	Page <b>2</b> of 18

# Table of contents

1	ORGANIZATION OF THE HW4 MANUALS	3
2	OVERVIEW	4
3	INITIAL SETUP	4
3.1 3.2	USB dongle wireless adapter LAN wireless adapter	
4	SEARCHING FOR THE WIRELESS ADAPTER AND DATA LOGGERS	6
4.1 4.2 4.3	Adapters Tab Devices Tab Signal Strength Tab	7 9 10
5	HW4 Device Tree	11
6	DEVICE MANAGER	11
6.1 6.2 6.3	Device Manager Form Menu Bar Device Information Settings	12 13 14
7	DATA LOGGING	
7.1 7.2	Data Logging Form Menu Bar Adding a calculated parameter to the log file	17 17
8	DOCUMENT RELEASES	

E-M-HW4v3-F2-021_10	
---------------------	--

Document code

Rotronic AG Bassersdorf, Switzerland Unit

HW4 software v.3: Device Manager and Data Logging LOG-RC Series Data Loggers

Instruction Manual

Document Type

Document title

Page 3 of 18

## 1 ORGANIZATION OF THE HW4 MANUALS

The HW4 manuals are organized in separate books so as to limit the size of the individual documents. A list of the HW4 manuals is provided in document **E-M-HW4v3-DIR** 

HW4 Manuals	Contents		
HW4 Main Book	General software description Installation, start-up and settings Device connection methods Functions common to all devices used with HW4		
Device Specific Functions 1 (separate book for each device type or model)	<ul> <li>Legacy devices (original HygroClip technology):</li> <li>HygroLog NT data logger</li> <li>HygroFlex 2, HygroFlex 3 and M3 transmitters (same icon in device tree)</li> <li>HygroLab 2 and HygroLab 3 bench indicators</li> <li>HygroPalm 2 and HygroPalm 3 portable indicators</li> <li>HygroClip DI digital interface</li> <li>HygroClip Alarm programmable logic</li> <li>HygroStat MB</li> <li>Device Manager (device configuration) and other device specific functions</li> </ul>		
Probe Adjustment 1	Humidity and temperature adjustment function common to all legacy devices (original HygroClip technology)		
Device Specific Functions 2 (separate book for each device type or model)	<ul> <li>Devices based on the AirChip 3000 technology:</li> <li>HygroClip 2 (HC2) probes</li> <li>HF3 transmitters and thermo-hygrostats</li> <li>HF4 transmitters</li> <li>HF5 transmitters</li> <li>HF6 transmitters</li> <li>HF7 transmitters</li> <li>HL20 and HL21 data loggers</li> <li>HP21, HP22 and HP23 hand-held indicators</li> <li>HygroLab C1 table-top indicator</li> <li>LOG-RC Series Data Loggers</li> <li>Custom designed OEM products</li> </ul>		
Probe Adjustment 2	Humidity and temperature adjustment function common to all devices based on the AirChip 3000 technology		
Data Recording Function	Data recording function common to all devices based on the AirChip 3000 technology		

Both the HW4 manuals (software) and device specific manuals (hardware) are available from the HW4 CD. The manuals can also be downloaded from several of the ROTRONIC web sites.

E-M-HW4v3-F2-021_10	Rotronic AG Bassersdorf, Switzerland	
Document code	Unit	
HW4 software v.3: Device Manager and Data	Instruction Manual	
Logging Loo-No benes Data Loggers	Document Type	
Document title	Page <b>4</b> of 18	

## 2 OVERVIEW

This section of the HW4 manual covers only the following HW4 modules:

HW4 Functional Modules LOG-RC Series Data Loggers	Usage	
Device Manager	<ul> <li>User configurable settings for the data loggers and associated accessories</li> </ul>	
Data Logging	<ul> <li>Memory status, log interval setting and data download</li> </ul>	

- Calibration / Adjustment: HW4 does not allow calibrating or adjusting the LOG-RC series data loggers. The HygroClip probe that is used with model LOG-HC2-RC cannot be calibrated or adjusted while connected to the data logger. HW4 can be used to calibrate and adjust a HygroClip probe that is directly connected to the HW4 PC by means of a service cable such as cable AC3001. For instructions, please see the HW4 manual E-M-HW4v3-A2-001
- o HW4 functions that are not device dependent are covered in the HW4 manual E-M-HW4v3-Main.

## 3 INITIAL SETUP

The LOG-RC series data loggers use the following radio frequencies to communicate with the HW PC: 433.92 MHz (standard) or 915 MHz (USA).

Communication with the HW4 PC requires one of the following types of adapter:

- o USB dongle wireless adapter
- LAN wireless adapter (Ethernet TCP/IP protocol)

In principle, you may use as many LAN adapters as required by your application but you can only one USB dongle adapter.

## 3.1 USB dongle wireless adapter

The USB dongle wireless adapter requires a driver in order to communicate with the HW4 PC.

#### IMPORTANT:

- Do not run HW4 while installing this driver
- Do not plug-in the USB dongle to the HW4 PC before installing the driver

#### 3.1.1 USB Driver installation

As part of its installation process, the HW4 installer creates a directory labeled "**USB\_Driver\_LOG-xxx-RC**" located in the HW4 installation folder:

_			
	E-M-HW4v3-F2-0	21_10	Rotronic AG Bassersdorf, Switzerland
0	ocument code		Unit
	HW4 software v.3: [	Device Manager and Data	Instruction Manual
	logging LOG-RC S	eries Data Loggers	Document Type
[	ocument title		Page <b>5</b> of 18
	<u>File E</u> dit <u>V</u> iew F <u>a</u> vorites	Iools <u>H</u> elp	
	Ġ Back 🝷 🕥 🕤 🏂	🔎 Search 🏾 🍺 Folders 🛛 📴 🍞 🗙 🖁	<b>9</b>
	Address 🛅 C:\HW4_310		
	Name 🔺	Size Type Date	e Modified
	DATA	File Folder 9/21,	/2011 11:33
	DATA_ONLINE	File Folder 9/21,	/2011 11:33
	DOC	File Folder 9/21,	/2011 11:33
	EVENT	File Folder 9/21,	/2011 11:33
		File Folder 9/21,	/2011 11:34
		File Folder 9/21,	/2011 11:34
		File Folder 9/21,	/2011 11:34
	SVS	File Folder 9/21,	/2011 11:33
	🗀 tools	File Folder 9/21,	/2011 11:34

Open the directory and double click on the file named CDM2.04.16.exe. This automatically installs on the HW4 PC the driver required to use USB dongle wireless adapter

9/21/2011 11:34

9/21/2011 11:34 7/16/2007 10:30

File Folder

File Folder

118 KB Wave Sound



USB\_Driver

Alarm.wav

At this point you can plug-in the USB dongle wireless adapter to the HW4 PC and Windows should automatically associate the driver to the USB dongle. When this is done you can run HW4 and search for any available data logger as explained later on in this manual.

## 3.2 LAN wireless adapter

The LAN adapter is factory configured to use DHCP (Dynamic Host Configuration Protocol) and should be used only on a LAN that includes a DHCP server such as a router or a managed switch.

With DHCP enabled, the DHCP server senses when a new device (or host) is connected to the network and automatically assigns / configures the device with the next available IP address. The device is also automatically configured with the network subnet mask and gateway address. Using DHCP is simple, guarantees compatibility with the network and eliminates the possibility of conflicting IP addresses.

An IP address assigned using DHCP is also known as a dynamic address. As long as DHCP remains enabled on the host, the host IP address is subject to change. This is not desirable when using HW4.

Once the dynamic address of the host is known, and communication with the host can be established, we recommend to change the host IP address to an unused network address and to disable DHCP on the host. In this manner, the new host IP address is a static address, not subject to change.

When using more than one LAN adapter, make sure to give each one a unique name (or network name). See further down in this manual for instructions.

E-M-HW4v3-F2-021_10	Rotronic AG Bassersdorf, Switzerland
Document code	Unit
HW4 software v.3: Device Manager and Data	Instruction Manual
Logging LOG-NG Series Data Loggers	Document Type
Document title	Page <b>6</b> of 18

# 4 SEARCHING FOR THE WIRELESS ADAPTER AND DATA LOGGERS

Do one of the following:

Connect the USB dongle wireless adapter to the HW4 PC (after having installed the required USB driver)

or

• Power up the LAN wireless adapter and connect it to the same LAN as the HW4 PC.

Note: in principle there is no limit as to the number of adapters that can be simultaneously used. However only a single USB dongle adapter is permitted.

The Rotronic wireless data loggers are set by the factory to automatically transmit measurement data whenever interrogated by HW4. Initially, make sure that the data loggers are within a few meters (or yards) of the wireless adapter.

Start HW4 and use the HW4 main menu bar as illustrated below:

نگ <sup>و</sup> HW4								
File	Dev	rices and Groups	View	Settings a	ind Too	ols	Help	
i 🖻 🛛		Search for Master Devices				USB Masters		
- ji		Search for RS-485 Slave Devices				RS-232 Masters (COM port)		
		Add Group					Ethernet Masters	
		Delete Group					Search a Specific IP Address	
		Add device					Search for LOG-XX-RC Devices	
		Delete Device					Refresh Master Devices	
		Delete all device	s from the	e tree				_
		Connection over	Modem					

E-M-HW4v3-F2-021_10	Rotronic AG Bassersdorf, Switzerland <sup>Unit</sup>
HW4 software v.3: Device Manager and Data Logging LOG-RC Series Data Loggers	Instruction Manual
Document title	Page <b>7</b> of 18

Click on "Search for LOG-XX-RC" to open the Search for Wireless Devices form.



The form has 3 tabs labeled "Devices", Adapters" and "Signal Strength".

## 4.1 Adapters Tab

Search for Wireless Devices	×
Status IP Address	Search
	Edit
	Add
	Remove
ОК	Cancel

The "Adapters" tab has 4 buttons located on the right hand side:

- Search: click on this button to detect any adapter (LAN or USB)
- Edit: this button works only with a LAN adapter and opens a form that can be used to change the network settings of the adapter
- Add: use this button to add a LAN adapter with a known IP address
- **Remove**: use this button to remove the selected adapter from the form

The adapters detected by HW4 are listed on the left hand side of the form. Any adapter can be selected by clicking on it with the mouse.

E-M-HW4v3-F2-021_10	Rotronic AG Bassersdorf, Switzerland	
Document code	Unit	
HW4 software v.3: Device Manager and Data Logging LOG-RC Series Data Loggers	Instruction Manual Document Type	
Document title	Page <b>8</b> of 18	

USB Dongle Wireless Adapter

#### LAN Wireless Adapter

Search for Wireless Devices	X	Search for	Wireless Devices	X
Devices Adapters Signal strength		Devices	Adapters Signal strength	
Status IP Address OK 192.168.57.180	Search Edit Add Remove	OK	IP Address [USB Dongle]	Search       Edit       Add       Remove
ОК	Cancel		OK	Cancel

The status reads "OK" when the adapter is working and when the HW4 PC can communicate with it. When a previously detected adapter can no longer be found, the status reads "unknown". In the case of a LAN adapter the form shows the IP address of the adapter. Whenever the IP address of a LAN adapter is not compatible with the LAN the status reads "invalid IP". In this case the adapter should be reconfigured as explained below.

## 4.1.1 Reconfiguring a LAN adapter

Select the "Adapters" tab and highlight the LAN adapter by clicking on it the mouse

Search for Wireless Devices           Devices         Adapters         Signal strength           Status         IP Address	Search Edit
Network settings MAC Address 00-00-5A-98-96-87 Use DHCP Name rotroniclan IP Address 192.168.57.180 Subnet Mask 255.255.255.0 Gateway 192.168.57.90	With the adapter selected, click on the "Edit" button and use the form shown to the left to change the adapter network settings.

E-M-HW4v3-F2-021_10	Rotronic AG Bassersdorf, Switzerland	
Document code	Unit	
HW4 software v.3: Device Manager and Data Logging LOG-RC Series Data Loggers	Instruction Manual Document Type	
Document title	Page <b>9</b> of 18	

## 4.2 Devices Tab

The Devices Tab is used to make HW4 detect the wireless data loggers that are currently communicating with the wireless adapter(s). To do this, click on the "Search" button located at the bottom of the form.

Search for Wireless Devices	×
Devices Adapters Signal strength	
select all unselect all	
Search	
	1
Cancel	

Search for Wireless Devices
Devices Adapters Signal strength
<ul> <li>✓ 12648455 - LOG-HC2-RC</li> <li>✓ 12779524 - LOG-PT1000-RC</li> <li>✓ 12910596 - LOG-PT1000-RC</li> </ul>
select all
Search
OK Cancel



The " $\mathbf{OK}$  " button is used to add the selected data loggers to the HW4 Device Tree as illustrated below.

Any device can be individually selected by clicking on the box located to the left of the device (a check mark appears). All devices can also be globally selected or de-selected.

E-M-HW4v3-F2-021_10	Rotronic AG Bassersdorf, Switzerland	
Document code	Unit	
HW4 software v.3: Device Manager and Data	Instruction Manual	
Logging LOG-RC Series Data Loggers	Document Type	
Document title	Page <b>10</b> of 18	

## 4.3 Signal Strength Tab

This tab is used to visualize the strength of the radio signal received by each adapter from the wireless data loggers.

- o Click on one of the available adapters to select it
- o Click on the button labeled "Show Devices"
- o Click on any device to select it and display the signal strength bar chart.

earch for Wireless Devices Devices Adapters Signal strength	
Select Adapter [USB Dongle] 192.168.57.180	Show Devices
Select Device 12648455 - LOGRC-HC2 12779524 - LOGRC-PT 12910596 - LOGRC-PT03	Signal strength 81%
OK	Cancel

E-M-HW4v3-F2-021_10	Rotronic AG Bassersdorf, Switzerland	
Document code	Unit	
HW4 software v.3: Device Manager and Data	Instruction Manual	
Logging LOG-RC Series Data Loggers	Document Type	
Document title	Page <b>11</b> of 18	

## 5 HW4 Device Tree



When HW4 has detected one or several wireless data loggers each device appears as an icon in the left pane of the HW4 main screen.

Click on the + sign to the left of any of the icons to display a list of the available functional modules (see below).

## 6 DEVICE MANAGER

The Device Manager module is used to configure the data loggers.



To select the Device Manager module, click on it with the left mouse button. HW4 opens the Device Manager form.

Device Manager automatically interrogates the data logger and downloads its current configuration.

E-M-HW4v3-F2-021_10	Rotronic AG Bassersdorf, Switzerland
Document code	Unit
HW4 software v.3: Device Manager and Data	Instruction Manual
Logging LOG-RC Series Data Loggers	Document Type
Document title	Page <b>12</b> of 18

Device Manager			X
File Tools Help			
Device Information Settings	Device Information		22.20
	Device Type	LOG-HC2-RC	1980 - 19 Table - 18
	Software Version	V2.0	
	Serial Number	12648455	
	Device Protection	Off	Change
	Time	10/31/2011 13:48:55	Set Date/Time
	Signal Strength	81%	S. J
	1.0	1:300	
		(	OK Cancel

The different sub-forms that are available within the Device Manager form are listed in a tree located on the left pane of the form. To select a sub-form, click on it with the left mouse button.

## 6.1 Device Manager Form Menu Bar

The Device Manager Menu bar is located at the top of the form.

#### File

• Close: closes the form

#### Tools

• Generate Protocol: generates a Device Configuration Protocol. This text file is automatically saved in the folder specified in HW4 Global Settings - File Locations Tab. If so desired, any directory and any file type may be specified. This action is not recorded in the User Event file.

#### Help:

- HW4 Help: Opens HW4 Help
- About HW4: Displays the version number and ID number of HW4

E-M-HW4v3-F2-021_10	Rotronic AG Bassersdorf, Switzerland
HW4 software v.3: Device Manager and Data Logging LOG-RC Series Data Loggers	Instruction Manual Document Type
Document title	Page <b>13</b> of 18

## 6.2 Device Information

Device Manager			×
File Tools Help			
Device Information Settings	Device Information		22.0
	Device Type	LOG-HC2-RC	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
	Software Version	V2.0	
	Serial Number	12648455	as the
	250		52 30 30
	Device Protection	Off	<u>Change</u>
	Time	10/31/2011 13:48:55	Set Date/Time
	Signal Strength	81%	1. N. 1. N. S.
			0.000.00
	1.360 12.71	10.0 10.00	12 - 22 - 23 - 24 - 24 - 24 - 24 - 24 - 2
		C	OK Cancel

• Device Protection: This function is used to prevent unauthorized access to critical functions such as configuration changes, humidity and temperature adjustment, etc. Click on the blue link labeled "Change" to activate or deactivate the device protection. The password is the 4 character access code that can be read from a sticker located on the device.

Device Protection	$\mathbf{X}$
Enter password	OK Cancel

Click on the Device Manager OK button to confirm the protection settings to the data logger.

• Set Date /Time: click on this link to set the date and time of the data logger to the date and time of the HW4

E-M-HW4v3-F2-021_10	Rotronic AG Bassersdorf, Switzerland <sup>Unit</sup>
HW4 software v.3: Device Manager and Data Logging LOG-RC Series Data Loggers	Instruction Manual Document Type
Document title	Page <b>14</b> of 18

## 6.3 Settings

The contents of this form depends on the model of data logger

#### LOG-HC2-RC Settings

Device Manager					X
File Tools Help					
Device Information	Settings	99			12.03
	Device Name	LOGRC-H	HC2		1
	Data Transmission	Solicited M	ode	<b>v</b>	W . N. 1
	Fixed Pressure	1013.25		hPa	an fail
	Calculation	No calcula	tion	~	
	Alarm Limits	Low	High	Hysterese	
	Humidity	0	0	0	
	Temperature	0	0	0	
	Calculation	0	100	0	
				ОК	Cancel

#### LOG-PT1000-RC Settings

Device Manager					X
File Tools Help					
Device Information Settings	Settings Device Name	LOGRC-F	т		Ο.
	Data Transmission	Solicited Mo	ode		
	2435			1000	
	Alarm Limits	Low O	High	Hysterese	
	100	N	263		
				OK Can	cel

• Device Name: As far as possible use a unique device name (maximum 12 characters)

E-M-HW4v3-F2-021_10	Rotronic AG Bassersdorf, Switzerland
Document code	Unit
HW4 software v.3: Device Manager and Data	Instruction Manual
Logging LOG-RC Series Data Loggers	Document Type
Document title	Page 15 of 18

#### • Data Transmission:

**Off**: the data logger does not send measurement data when polled by HW4. Device Manager and Data Logging are still fully functional

**Solicited Mode**: select this data transmission mode if you wish to display the measurement data on the HW4 main screen. In this mode the data logger sends measurement only when solicited by HW4 via the wireless adapter. Measurement data cannot be sent by the data logger any faster than once every minute. This means that when the HW4 polling interval is less than one minute, measurement data is received from the data logger only once every minute. To set the HW4 polling interval: use the HW4 Main Menu Bar > Settings and Tools > HW4 Global Settings > General Tab. It is important to note that the measurement data sent by the data logger is refreshed only at the rate of the log interval used by the logger (see Data Recording in this manual). Both the HW4 polling interval and the data logger log interval should be set by the user so as to conserve battery power.

**Unsolicited Mode:** the data logger automatically sends measurement data every 6 seconds. This data transmission mode is meant for use with data logger model LOG-GPRS-RC (under development)

- Fixed Pressure: use this field to enter a numerical value for calculated psychrometric parameters that require barometric pressure as an input value.
- Calculation: Left click on the arrow to the right of the text box and select from the following: No calculation, Dew Point, Frost Point or other psychrometric parameter. Please note that the data logger itself does not perform any calculation and that the calculation setting is not retained in the data logger. The calculation setting must be re-entered whenever the data logger is deleted from the Device Tree and is searched again.
- Lo-Alarm, Hi-Alarm, Hysteresis: Alarm conditions can be defined for humidity, temperature and the calculated parameter. Values that are below the low alarm value or above the high alarm value will trigger an alarm. The value specified for the alarm function hysteresis is used for both the low and the high alarm. To enable the alarm function click on the box located to the left of each parameter that you wish to monitor. A check mark appears in the box when monitoring is enabled.

All versions of HW4 show an out-of-limits value alarm by using red characters on the monitor screen. In addition, HW4 Professional can be configured (HW4 global settings - Alarm settings tab) to display an alarm table and generate a report whenever an out-of-limits condition occurs

Please note that the data logger itself does not monitor alarm conditions and that alarm settings are not retained in the data logger. The alarm settings must be re-entered whenever the data logger is deleted from the Device Tree and is searched again.

#### 6.3.1 Unit system

The unit system (metric / English) for both the measurement data displayed by HW4 and the recorded data downloaded to theHW4 PC is determined by the HW4 Global Settings (HW4 main menu bar > Settings and Tools > HW4 Global Settings, Language / Unit System tab)

E-M-HW4v3-F2-021_10	Rotronic AG Bassersdorf, Switzerland
Document code	Unit
HW4 software v.3: Device Manager and Data	Instruction Manual
Logging LOG-RC Series Data Loggers	Document Type
Document title	Page <b>16</b> of 18

## 7 DATA LOGGING

The Data Logging module is used to set the log interval, download the recorded data to the HW4 PC and clear the memory.

.

🍰 HW	4	
File	Devices and Groups	Vie
i 🖻 I	🗟 🛉 🦻   1:1 📂	uu min
<b>•</b> •••	LOG-HC2-RC	
	🥵 Device Manage	r 📗
	📕 Data Logging	
i 🕹	LOG-PT1000-RC	
Ť	🥋 Device Manage	r 📗
	🗔 Data Logging	

To select the Data Logging module, click on it with the left mouse button. HW4 opens the Data Logging form.

Data Logging		X .
File Tools Help		
····· <mark>Status / Data Download</mark>	Status / Data Down	Iload
	Memory Used	8,364 (0%)
	Log Interval	0:10:00 Change
	Memory full on:	5/31/2016
	Start Logging	
	13410	
	Download duration	2s
	Progress	
	Start download	
	10	
	-	Exit

Note: this series of data loggers is designed to record data continuously until the memory becomes full. No data recording stop function is provided.

<b>E-M-HW4v3-F2-021_10</b>	Rotronic AG Bassersdorf, Switzerland <sub>Unit</sub>
HW4 software v.3: Device Manager and Data Logging LOG-RC Series Data Loggers	Instruction Manual Document Type
Document title	Page <b>17</b> of 18

- o Log interval: 5 seconds to 12 hours, in 5 seconds increments.
- Change : click on this link to write the value of the log interval to the data logger

NOTE: Based on both the memory size and on the log interval, the form provides an estimate of the date when the memory will be full. At that time the data logger will stop recording data. The estimated date does not take into account the remaining battery lifetime or the effect of the log interval value on the battery power.

- Start Logging: click on this link to erase the memory contents and start recording a new set of measurement data
- Start Download: click on this link to download and view the recorded data. The type of file used for storing the recorded data on the HW4 PC can be set from the menu bar of the Data Logging form (Tools > File Format)

## 7.1 Data Logging Form Menu Bar

The Data Logging menu bar is located at the top of the form.

#### File

• Exit: This menu item closes the form

#### Tools

- File Format: use this menu item to set the file format (text file .txt or binary .log) that HW4 uses when saving the data to disk.
- Generate Protocol: generates a Log Settings Protocol. This text file is automatically saved in the folder specified in HW4 Global Settings File Locations Tab. If so desired, any directory and any file type may be specified. This action is not recorded in the User Event file.

#### Help:

- HW4 Help: Opens HW4 Help
- About HW4: Displays the version number and ID number of HW4

## 7.2 Adding a calculated parameter to the log file

HW4 View Data can be used to add a calculated parameter such as dew point to a log file comprised of relative humidity and temperature records. The parameter is calculated for each data record based on the relative humidity and temperature values.

HW4 View Data can also be used to replace the calculated parameter in a log file with a different one.

E-M-HW4v3-F2-021_10	Rotronic AG Bassersdorf, Switzerland
Document code	Unit
HW4 software v.3: Device Manager and Data Logging LOG-RC Series Data Loggers	Instruction Manual
Document title	Page <b>18</b> of 18

HW4 View Data opens automatically after downloading data from the data logger. Files that have already been downloaded can be opened from the HW4 main menu bar by selecting File > Open. To access the "**Add / Change calculated parameter**" function, click on **Tools** in the HW4 View Data menu bar and select "Add / Change calculated parameter". This opens the following form:

Select Calculated Parameter 🛛 🔀
<ul> <li>Dew point</li> <li>Frost point</li> <li>Wet-bulb temperature</li> <li>Enthalpy</li> <li>Vapor concentration (moist)</li> <li>Specific humidity (moist)</li> <li>Mixing ratio by Wt. (dry)</li> <li>Saturation vapor concentration</li> <li>Vapor partial pressure</li> <li>Vapor saturation pressure</li> </ul>
Fixed Pressure 1013.25 hPa
OK Cancel

Use the form shown on the left to select one of the available calculated parameters.

NOTE: some parameters such as Enthalpy, Mixing Ratio etc. require barometric pressure as a calculation input. Be sure to enter the correct pressure value in the form.

Click on the OK button to add the selected calculated parameter or change the existing calculated parameter.

## 8 DOCUMENT RELEASES

Release	Software Ver.	Date	Notes
_10	3.1.0	Oct. 31, 2011	Original release