ICON Lite Kit



Transmitter Configuration Kit with **USB** Communication



The ICON Lite Kit is for communication to the latest series of INOR transmitters -Models C/R 202, MINIPAQ-HLP/L, C/R 330, C/R 520 and C/R 530. The kit contains the INOR USB Interface, PC to USB Interface cable, USB Interface to Transmitter cable, and storage bag.

Communication with the connected transmitter is established automatically, without any problems to match the PC communication port to the software.

- USB communication
- Automatic matching of communication ports
- Automatic transmitter identification for guick start up
- Diagnostic LED's on the USB Interface show the communication status • Simple installation of configuration software and drivers for the USB Interface
- User Instructions and Installation Guide included (on USB memory stick)
- Free download of configuration software, Consoft, and USB Interface software from our website

Specifications:

Input (PC to USB Interface)	USB cable
Output (USB Interface to transmitter)	Changeable transmitter cables
Power Supply	From USB port
Ambient temperature	
Operation	0 to 50 °C / 32 to 122 °F
Storage	-20 to 70 °C / -4 to 140 °F
Humidity	0 to 90 % RH
Galvanic isolation	1500 VAC
JSB compliance	USB v.1.1 and USB v.2.0
system requirements	
Vindows	
Display resolution	Min. 800 x 600
Hard drive space	50 MB

Connection cables PC to USB Interface Part No-70KAB49817 USB Interface to IPAQ C/R 201 MinIPAQ-HLP/-L IPAQ C/R 330 IPAQ C/R 520 & C/R 530 HART Part No: 70KAB49717 **USB** Interface 36/1 42

Part No: 26/1 70USBI0001 mm/inch

Ordering information

ICON Complete Configuration Kit	70CFGUS101
Separate parts	See above

Contact: Industrial Process Measurement, Inc. 3910 Park Avenue, Unit 7 Edison, NJ 08820 732-632-6400 support@instrumentation2000.com http://www.instrumentation2000.com

