K-THERMOMETER

(K-type thermocouple - Dual input)

MODEL CA863

USER MANUAL _____

The AEMC® Model CA863 is a portable, easy-to-use, compact-sized, dual input digital thermometer, designed for simple one-hand operation. It uses two external K-type thermocouples with standard miniature connectors as sensors. The thermometer is supplied with a protective holster and two K-type thermocouples. The Model CA863 also features a back-light LCD display, a data HOLD function, and a MAX recording function.



- Thermometers are not designed to work on live electrical samples.
- Do not use this instrument when voltages at the sample point exceed 24VDC or 24Vrms.
- Do not make temperature measurement in microwave ovens. Leaking microwaves may result in burns and serious injuries.
- Repeated sharp flexing can cause the thermocouple leads to break. To prolong sensor life, avoid sharp bends in the thermocouple, especially near the connector.



This symbol signifies CAUTION! and requests that the user refer to the user manual before using the instrument.

PUSH BUTTONS

Center (Yellow) Function Switch:

Slide the center button to turn ON the Thermometer and select the 0.1° or 1° setting. Slide the button to OFF after use.

Back-Light * and °C/°F Button:

- Press the 🔆 button to turn the Back-Light ON.
- Press the button again to turn the Back-Light OFF.
- Press the * button for 2 seconds to change the temperature scale to °C or °F. The
 temperature scale °C or °F is displayed in the lower right hand side corner of the
 display.

HOLD/MAX Button:

- Pressing the HOLD/MAX button once will initiate the data HOLD mode. The "HOLD" annunciator appears in the upper right hand corner of the display.
- The Hold button "freezes" the reading and stops all further measurement updates.
- Pressing the HOLD/MAX button again will initiate the MAX mode. The "MAX" annunciator appears in the upper right hand corner of the display.
- In the MAX mode, the thermometer automatically displays and updates the maximum absolute values.
- To exit the MAX mode, press the MAX button again. The Model CA863 will be in a normal (non MAX or HOLD) mode at power up.



T1/T2 - AT Button:

- Pressing the T1/T2 ΔT Button selects in sequence T1, T2 and ΔT . ΔT is the temperature difference T2- T1.
- The actual measurement T1, T2, T2-T1 is displayed in the upper left hand corner of the LCD.

OPERATING INSTRUCTIONS

OPERATION

- 1. Connect the K-type thermocouples to the instrument input.
- 2. Put the thermocouples near or on the sample tested.
- Slide the function switch to the appropriate range or, if in doubt, select the highest setting (1°). If the measured temperature is below 200°, the higher resolution range 0.1° can be selected, if needed.
- 4. The Model CA863 may be in degrees Celsius (°C) at power-up. Press the back-light button for more than 2 seconds to toggle over into degrees Fahrenheit (°F), if desired. The selected setting will remain for the next use.
- Thermocouples need a certain time to respond. Take the reading when the measurement has stabilized.
- The HOLD button will freeze the measurement in the display, and will not update until released.
- 7. When finished, remove the thermocouple from the sample, unplug the thermocouple from the meter and slide the switch to OFF.

SPECIFICATIONS

ELECTRICAL

Temperature Scale:

Celsius (°C) or Fahrenheit (°F) user-selectable

Measurement Range (Dual Input):

-58°F to 1999°F (-50°C to 1300°C)

Resolution:

0.1°F/°C or 1°F/°C

Accuracy (meter):

-58°F to 1999°F: ± 0.3% rdg + 2°F* -50°C to 1000°C: ± 0.3% rdg + 1°C* 1000°C to 1300°C: ± 0.5% rdg + 1°C*

*plus thermocouple

Temperature Coefficient:

0.1 times the applicable accuracy specification per °C from 0°C to 18°C and 28°C to 50°C.

Input Protection:

24VDC or 24Vrms maximum input voltage on any combination of inputs.

Input Connector:

Accepts standard miniature K-type thermocouple connectors.

Temperature Response:

Temperature indication follows Reference Temperature/Voltage Tables N.I.S.T.

Monograph 175 Revised to ITS-90 for K-type thermocouples.

GENERAL

Display:

31/2 digit liquid crystal display (LCD) with maximum reading of 1999

Over-Range: "OL" is displayed

Low Battery Indication:

The -+ is displayed when the battery voltage drops below the required level

Sample Rate:

2.5 times per second, nominal

Operating Temperature:

32° to 122°F (0°C to 50°C) at < 80%RH

Storage Temperature:

-4°F to 140°F (-20°C to 60°C), 0 to 80%RH with battery removed

Altitude: 2000m max

Battery:

Standard 9V battery (NEDA 1604, IEC 6F22 006P, or equivalent)

Battery Life:

200 hours typical with carbon zinc battery

Dimensions:

6.81"(H) x 2.38"(W) x 1.5"(D) (173 x 60.5 x 38mm)

Weiaht:

Approx. 6.4oz (181g) including battery

Probe: The Thermometer CA863 is supplied with two 4 ft K-type thermocouples bead probe (Teflon sheath). Maximum sheath temperature 260°C (500°F). Probe accuracy ±2.2°C (4°F) or ±0.75% of reading (whichever is greater) from 0°C to 800°C.

Contact AEMC® for other thermocouples available.

SAFETY



EN61010-1 (1995-A2), Protection Class III Overvoltage Category (CAT III, 24V), Pollution Degree 2 Indoor Use

POPERATOR MAINTENANCE



To avoid possible electrical shock, disconnect the thermocouple connectors from the thermometer before opening the back cover.

Use only factory specified spare parts for maintenance. The manufacturer will not be held responsible for any accident, incident, or malfunction following a repair done other than by its Service Center or by an approved repair center.



Battery Replacement:

A standard 9-volt battery supplies power. (NEDA 1604, IEC 6F22). The ___ appears on the LCD display when replacement is needed.

To replace the battery:

- Turn the Thermometer OFF
- Remove the rubber holster.
- Remove the screw from the back of the meter and lift off the battery cover.
- · Replace the battery, rear cover and holster.



Cleaning:

- Periodically wipe the case with a damp cloth and very mild soap, if needed.
- · Do not use any abrasives or solvents.
- Do not let any liquid enter the case or sensor area.

TREPAIR AND CALIBRATION

To guarantee that your instrument complies with the factory specifications, we recommend that the unit be submitted to our factory service center at one-year intervals for recalibration, or as required by other standards. For repair and/or calibration:

> Chauvin Arnoux®, Inc. d.b.a. AEMC® Instruments 15 Faraday Dr. • Dover, NH 03820, USA (800) 945-2362 • (603) 749-6434 • Fax: (603) 742-2346 www.aemc.com

(Or contact your authorized distributor.) Costs for repair, standard calibration, and calibration traceable to N.I.S.T. are available.

All customers must call for a return authorization number before returning any instrument.

TECHNICAL AND SALES ASSISTANCE

If you are experiencing any technical problems, or require any assistance, contact us at: (800) 343-1391 • (508) 698-2115 • Fax: (508) 698-2118 www.aemc.com

WARRANTY INFORMATION

The Digital Thermometer Model CA863 is warranted to the owner for a period of 1 year from the date of original purchase against defects in manufacture. This limited warranty is given by AEMC® Instruments, not by the distributor from whom it was purchased. This warranty is void if the instrument has been tampered with, abused or if the defect is related to service not performed by AEMC® Instruments.

For full warranty coverage detail and registration, go to www.aemc.com.

To return the product for warranty repair or replacement free of charge, contact customer service at (800) 945-2362 or (603) 749-6434 to obtain a return authorization number.