Additel 761A Series Automated Pressure Calibrators





- Automated and self-contained pressure generation and control to 1,000 psi (70 bar)
- Precision accuracy models to 0.01%FS
- Standard accuracy to 0.02%FS
- Two removable internal pressure modules for multi-range selection
- Control stability to 0.003%FS
- Portable, designed for use in the field and in the lab
- Ability to measure two external pressure modules
- Wi-Fi, Bluetooth, USB and Ethernet communication
- Full HART field communicator
- HART and profibus communication
- Data logging and task management
- Patented electric pump technology and improved speed

AUTIS-47-CPM Former Children Francesch Australia Former Children Francesch Australi

OVERVIEW

At Additel, innovation and continuous improvement are part of our company's culture and the products we introduce. When we set out to deliver the Additel 761A series calibrators, we knew we needed to provide breakthrough improvements and additional value to the existing line of calibrators (Additel 761 series). The ADT761A has many improvements: increased pressure range to 1,000 psi (70 bar), removable internal pressure modules, precision accuracy models available to 0.01%FS, increased speed to pressure, ability to read two external pressure modules, touch screen display, Wi-Fi, Bluetooth, and Ethernet communications, double the original battery life, and more!

Just like the first generation, this second generation product is completely self-contained and automated with a built-in pump for pressure generation and precision control technology. Simply set the desired pressure and watch the calibrator do the work.

Addite

Metrology Made Simple

ADT761A-LLP

The Additel 761A-LLP is designed for low pressure calibration and comes with a ± 30 inH2O (± 75 mbar) high range module and a low range module of your choice ranging from ± 20 inH2O to as low as ± 0.25 inH2O (± 50 to ± 0.62 mbar). This unit has an accuracy of 0.05%FS with control stability better than 0.005%FS. All measurements can be made in differential or gauge pressures.



ADT761A-D

The Additel 761A-D also provides differential and gauge measurement which covers the range of -13.5 to 35 psi (-0.95 to 2.5 bar). This unit comes with a CP35 module (-13.5 to 35 psi) and one low range module of your choice ranging as low as ± 10 inH2O (25 mbar). Each ADT761A-D can be preconfigured with the modules that fit your need to give you the best precision at the pressures you perform calibrations.



The Additel 761A-500 will generate and control from vacuum pressures up to 500 psig (35 bar.g). Both gauge and absolute pressures can be realized due to a built-in barometer. Each unit comes with a CP500 module (-13 to 500 psig) for the high range and the low range can be preconfigured based on the variety of modules available down to 10 psig (0.7 bar.g).



ADT761A-1K

The Additel 761A-1K will generate and control from vacuum pressures up to 1,000 psig (70 bar.g). This unit can typically achieve 1,000 psi in less than 45 seconds. Like the ADT761A-500, both gauge and absolute pressures can be realized due to a built-in barometer. Each unit comes with a CP1K module (-13 to 1,000 psig) for the high range and the low range can be preconfigured based on the variety of modules available down to 30 psig (2 bar.g).



ADT761A-BP

The Additel 761A-BP is designed for calibration of barometer sensors. With a range of 100 to 1200 hPa and an accuracy of 0.01%FS, this unit is ideal for calibration on the bench or in the field.

Pressure Specifications

Model Specification	761A-IIP		761A-500	761A-1K	761A-BP		
Max Pressure Range	30 inH2O (75 mbar)	35 psi (2.5 bar)	500 psig (35 bar.g)	1,000 psig (70 bar.g)	1,200 hPa		
Min Pressure Range	-30 inH2O (-75 mbar)	-13.5 psi (-0.95 bar)	-13 psi (-0.9 bar)	-13 psi (-0.9 bar)	100 hPa		
Accuracy ⁽¹⁾	0.05%FS	0.02%FS	User selectable: 0.01%FS or 0.02%FS	User selectable: 0.01%FS or 0.02%FS	0.01%FS		
Stability	0.003%FS or 0.03 Pa	0.003%FS	0.003%FS	0.003%FS	0.02 hPa		
Pressure Type	Differential, Gauge	Differential, Gauge	Gauge, Absolute	Gauge, Absolute	Absolute		
Over Range Indication	120%						
Resolution	6 digits						
Measurement Units	Pa, hPa, kPa, mPa, bar, mbar, psi, mmHg@0°C, cmHg@0°C, mHg@0°C, inHg@0°C, inH2O@4°C, mmH2O@4°C, cmH2O@4°C, mH2O@4°C, mmH2O@4°C, mmH2O@20°C, cmH2O@20°C, mH2O@20°C, inH2O@20°C, inH2O@68°F, kgf/cm2, mtorr, torr, lb/ft2, tsi, custom						
Barometric Accuracy	N/A	N/A	55 Pa	55 Pa	N/A		

^[1] One year accuracy (including 1 year stability). FS specification applies to the span of the module range.

Electrical Specifications

Model Specification	Range	Resolution	Accuracy	Note		
mA Measure	Auto-ranging ±25 or ±50 mA	0.1 μΑ	0.008%RD+0.004%FS	Impedance <10Ω		
V Measure	±300 mV	1 μV	0.008%RD+0.002%FS	Impedance >1 GΩ		
v measure	Auto-ranging ±5, ±12 or ±30 V	±5 V:20 μV ±12 V:100 μV ±30 V:100 μV	0.008%RD+0.002%FS	Impedance >1 MΩ		
Loop Power Source	24 V	N/A	±0.24 V	50 mA (Max Loading)		
mA Source	0 to 2.5 mA or 2.5 to 25 mA	0-2.5 mA: 0.05μA 0-25 mA:0.5μA	0-2.5 mA: 0.008%RD+0.1 μA 0-25 mA: 0.008%RD+1.0 μA	20 mA @ 1 KΩ		
Power Source	16 to 30 V	1 V	±1 V	70 mA (Max Loading)		
V Source	0 to 16 V	250 μV	0.008%RD+0.002%FS			
Pressure Switch	Mechanical Switch, Live Mechanical Switch, NPN Switch, PNP Switch	N/A	N/A	Response time<10 ms. If the switch is live, voltage range will be (3-30) V		
Temperature Compensation	15°C to 25°C					
Temperature Coefficient	Outside of 15°C to 25°C: <±0.0005%RD+0.00005%FS/°C					
Misuse Protection	Up to 30 V on any two sockets					

^[2] Specification based on gauge measurement. An additional 55 pa uncertainty will need to be included when measuring in absolute mode. Applicable only for use with the ADT761A-500 and ADT761A-1K.

^{*} Additel 761A calibrators support 161 series intelligent digital pressure modules that are available for gauge, vacuum pressure from -15 psi to 60,000 psi (-1 bar to 4,200 bar). For detailed specifications refer to the 161 series pressure modules datasheet.



Internal Module Specification and Compatibility

Metrology Made Simple

							107	etrology ii	ruuc Oiiii
Model Range	inH2O ^[6]	mbar ^[6]	Media	Accuracy (%FS) ^[1]	Burst Pressure	761A-LLP	761A-D	761A-500	761A-1K
ADT155-20-DP025	±0.25	±0.62	G	0.2 [2]	100x	•			
ADT155-10-DP050	±0.5	±1.25	G	0.1 ^[3]	100x	•			
ADT155-05-DP1	±1	±2.5	G	0.05 ^[4]	100x	•			
ADT155-05-DP2	±2	±5	G	0.05 ^[4]	100x	•			
ADT155-05-DP5	±5	±10	G	0.05 ^[4]	50x	•			
ADT155-05-DP10	±10	±25	G	0.05 ^[4]	20x	•	•		
ADT155-05-DP20	±20	±50	G	0.05	20x	•	•		
ADT155-05-DP30	±30	±75	G	0.05	20x	•	•		
ADT155-05-DP50	±50	±125	G	0.05	Зх		•		
ADT155-02-DP100	±100	±250	G	0.02	3x		•		
ADT155-02-DP150	±150	±350	G	0.02	3x		•		
ADT155-02-DP300	±300	±700	G	0.02	3x		•		
ADT155-02-DP400	-380 to 400	-950 to 1K	G	0.02	3x		•		
ADT155-02-DP800	-380 to 800	-950 to 2K	G	0.02	3x		•		
ADT155-02-DP1K	-380 to 1K	-950 to 2.5K	G	0.02	3x		•		
Gauge Pressure	psig	bar.g							
ADT155-02-CP10	±10	±0.7	G	0.02 ^[5]	3x		•	•	
ADT155-02-CP15	-13.5 to 15	-0.95 to 1	G	0.02 ^[5]	Зх		•	•	
ADT155-01/02-CP30	-13.5 to 30	-0.95 to 2	G	0.01 ^[7] / 0.02 ^[5]	Зх		•	•	•
ADT155-01/02-CP35	-13.5 to 35	-0.95 to 2.5	G	0.01 ^[7] / 0.02 ^[5]	3x		•	•	•
ADT155-01/02-CP50	-13.5 to 50	-0.95 to 3.5	G	0.01 / 0.02 ^[5]	3x			•	•
ADT155-01/02-CP100	-13.5 to 100	-0.95 to 7	G	0.01 / 0.02 ^[5]	3x			•	•
ADT155-01/02-CP150	-13.5 to 150	-0.95 to 10	G	0.01 / 0.02 ^[5]	3x			•	•
ADT155-01/02-CP200	-13.5 to 200	-0.95 to 14	G	0.01 / 0.02 ^[5]	3x			•	•
ADT155-01/02-CP300	-13.5 to 300	-0.95 to 20	G	0.01 / 0.02 ^[5]	3x			•	•
ADT155-01/02-CP500	-13.5 to 500	-0.95 to 35	G	0.01 / 0.02 ^[5]	3x			•	•
ADT155-01/02-CP600	-13.5 to 600	-0.95 to 40	G	0.01 / 0.02 ^[5]	3x				•
ADT155-01/02-CP1K	-13.5 to 1K	-0.95 to 70	G	0.01 / 0.02 ^[5]	3x				•
11 FS specification a	applies to the en	on of the mode	Ja vanas A		ana waar atabilit	. aveant for	DDOOF to DI	210 madulas	

^[1] FS specification applies to the span of the module range. Accuracy includes one-year stability, except for DP025 to DP10 modules.
[2] Accuracy is a 6 months spec, 1-year long-term drift is 0.2%FS.
[3] Accuracy is a 6 months spec, 1-year long-term drift is 0.1%FS.
[4] Accuracy is a 6 months spec, 1-year long-term drift is 0.05%FS.

^[5] Specification based on gauge measurement. An additional 50 Pa uncertainty will need to be included when measuring in absolute mode.

^[6] The low module pressure range may be outside the pressure range of the calibrator.

Applicable only for use with the ADT761A-500 and ADT761A-1K.

^{[7] 0.01%}FS accuracy specification not available for 761A-D models.

ADT155 Pressure modules are calibrated in psi & inH2O.


•



Metrology Made Simple

General Specifications

Specification	Description				
User Interface	Color touch screen and/or keypad operation				
Channels	Four total: one electrical, high or low internal pressure module, two external pressure modules				
Enclosure IP Rating	IP31				
Battery	Rechargeable Li-Ion battery, typically 12 hours of operation, recharges in less than 5 hours.				
Power	Rechargeable Li-Ion battery, external power 110/220 V power adapter 27 V				
Display	7" TFT touch screen 800 x 480 color				
Communications	USB, LAN, Bluetooth, Wi-Fi				
Weight	<17.52 lb (7.95 KG)				
Size	11.77 x 7.60 x 7.56 in (299 x 193 x 192 mm)				
Certification	ISO 17025 accredited certificate of calibration with NIST-traceable data				
Data Storage	6 GB				
Data Logging	Up to 1,000,000 readings (data and time stamped)				
HART Communicator	Read, configure and calibrate HART devices - DD files updated periodically				
Task documentation	Up to 1000 tasks can be stored with data				
Automation Functions	Switch test, auto step, leak test				
User Interface Localization	English, German, French, Italian, Spanish, Portuguese, Chinese, Japanese, and Russian				
Pump life	>1,000,000 cycles				
	Operating temperature: 32°F to 122°F(0°C to 50°C)				
Environmental	Compensated temperature: 32°F to 122°F(0°C to 50°C)				
Specifications	Storage temperature: -20°C to 60°C (-4°F to 120°F)				
	Humidity: <90%, non-condensing				
Vibration and Shock Vibration: 4 g (20 to 2,000 Hz) Shock: 8 g, 1 meter drop test					
Compliance	CE				
Software Compatibility	ACal, Additel Land and Additel Link for access via mobile application				
Warranty	1 year				



Pressure Range


				High-Range Pr	essure Module	Low-Range Pressure Module		
	Туре	Model	Pressure Range	Range	Accuracy	Range	Accuracy	
	Low / Differential	ADT761A-LLP-05-DPXX	-75 to 75 mbar (-30 to 30 inH2O)	DP30: -75 to 75 mbar (-30 to 30 inH2O)	0.05% FS	User selectable from DP20 to DP025	See Internal Module Table	
Pressure	ADT761A-D-02-DPXX-X	-0.95 to 2.5 bar (-13.5 to 35 psi)	CP35: -0.95 to 2.5 bar (-13.5 to 35 psi)	0.02% FS	User selectable from DP10 to CP30	See Internal Module Table		
	Standard Accuracy Gauge / Absolute Pressure	ADT761A-500-XX-CPXX-X	-0.9 to 35 bar (-13 to 500 psi)	CP500: -0.9 to 35 bar (-13 to 500 psi)	User selectable: 0.01%FS or 0.02%FS	User selectable from CP10 to CP300	See Internal Module Table	
		AADT761A-1K-XX-CPXX-X	-0.9 to 70 bar (-13 to 1000 psi)	CP1K: -0.9 to 70 bar (-13 to 1000 psi)	User selectable: 0.01%FS or 0.02%FS	User selectable from CP30 to CP600	See Internal Module Table	

05

•



Metrology Made Simple



Optional Accessories					
ADT161	See datasheet of ADT161 for more info; connection cable sold separately				
9060	Pressure module connection cable				
9530	Additel/ACal Automated Calibration Software				
ADT100-761Hose	ADT761 hose, 5 feet (polyamide, 2,390 psi burst)				
ADT106A-X	External Pressure Manifold (Excl ADT761A-LLP)				
ADT100-761A-X	Hose Test Kit, 5 feet flexible hose				

metrology made simple							
Accessories (included)							
ADT106A-X External Pressure Manifold (Excl ADT761A-LLP)	1 pc						
9818 110V/220V external Power adapter	1 pc						
9725 Chargeable Li-ion battery	1 pc						
9240 DP gauge holder, rubber (Only for ADT761A-LLP)	1 pc	Y					
9060 (Pressure module connection cable)	1 pc						
ADT100-761A-X Hose Test Kit, 5 feet flexible hose (excl ADT761A-LLP)	1 pc + 1 pc adapter						
1220211206 Adapter, quick female to barb (Only for ADT761A-D)	1 pc	- Canada					
9022 Test Leads for calibrator	2 sets (4 pcs)						
9907 Carrying case for 761A calibrator and accessory	1 pc						
O-rings	20 pcs						
Pressure Hose	1 pc for the ADT761A-D 1 pc for the ADT761A-BP	0					
ISO17025 accredited calibration certificate	1 pc						
Threaded plug (Excl ADT761A-LLP)	1 pc						
USB Cable	1 pc	O_					
Barb Fitting (Only for ADT761A-D and ADT761A-BP)	1 pc						
Silicone Tube	2 meters for the ADT761A- LLP 1 meter for the ADT761A-D						

06