



Snifit[®] 40 & 50

Carbon Monoxide Analyzers



Bacharach's affordable Snifit Carbon Monoxide (CO) analyzers can help you accurately measure CO concentration levels in room air. This continuous operating instrument quickly and accurately measures levels of CO between 0 and 1,999 ppm. Weighing just 8 ounces, the Snifit analyzers are light as a feather and small enough to fit in your shirt pocket or hold in the palm of your hand.

With one button operation, the Snifit analyzers are simple to use. Special design features such as a zero adjustment control and a fast response sensor specific to CO gas make the Snifit analyzers perfect for measuring low levels of CO.



Applications

The Snifit is ideal for ambient air safety checks on residential appliances such as fireplaces and ovens; home inspection and HVAC service on furnaces and hot water heaters.

Features

- Measures and displays Carbon Monoxide 0-1,999 ppm, 1ppm resolution
- Small enough to fit in your shirt pocket
- Back light for low light conditions (Model 50)
- One button operation
- Low battery indicator (Model 50)

Snifit Model 40

ATTACHMENT CO ANALYZER

In conjunction with your Digital Multimeter (DMM), the Snifit 40 will allow you to measure CO concentrations between 0 and 1,999 ppm. Simply plug in the universal Snifit connector into your DMM and conduct quick and easy CO measurements in room air. Use 3½ digit or greater DMM having a 2 V DC range or auto ranging capability and 100MΩ or greater input impedance.

Snifit Model 50

CO ANALYZER

The stand alone Snifit 50 allows you to continuously measure and display CO levels between 0 and 1,999 ppm. With 1 ppm resolution, the Snifit 50 can accurately measure high and low concentrations quickly and easily. The highly visible display indicates ppm CO and a backlight is available to use in low light conditions.

SPECIFICATIONS	
Range	0-1,999 ppm
Resolution	1 ppm
Display	3½" display with yellow-green backlight (Snifit 50 only)
Sensor Type	Electrochemical (specific to CO)
Sensor Calibration	Factory calibrated on 100 ppm
Sensor Accuracy	+/- 5% of reading
Weight	8 ounces (.23 Kg)
Dimensions	5.5"L x 2.0"W x 1.57"H (140mm x 50 mm x 40 mm)
Power Source	9-volt battery
Battery Life	6 months operation with normal duty cycles
Manual Zero	Reduces chances of zeroing in hazardous environment
Auto Power Off	Every 30 minutes
Operating Temp.	32°F to 104°F (0-40°C)
Warranty	1 year

ORDERING INFORMATION	
PART NO.	DESCRIPTION
19-7059	Snifit 40 CO Analyzer (used with multimeter)
19-7060	Snifit 50 CO Analyzer (used with digital display)
19-7061	CO Sensor
19-7065	Snifit Pump and Hose Assembly
19-3225	Coiled Cord for Multimeter
19-3242	Calibration Cup with screwdriver
54-1994	Calibration Gas (100 ppm)
24-7059	Calibration Kit (without gas)

Contact:
Industrial Process Measurement, Inc.
3910 Park Avenue, Unit 7
Edison, NJ 08820
732-632-6400
support@instrumentation2000.com
http://www.instrumentation2000.com