



**DIGI-SENSE™**  
THE STANDARD IN PRECISION MEASUREMENT



**Precalibrated &  
Ready to Use!**

## Pin-Style Pocket Moisture Meter

**Operate with just one hand!**

Rugged meter measures moisture level in wood products (sawn timber, cardboard, and paper) and hardened materials (plaster, concrete, and mortar).

### Features

- ◆ Reliable measurements, guaranteed!  
Precalibrated to NIST-traceable standards.\*
- ◆ Easy-to-use! Insert pins into material and repeat throughout test area
- ◆ Convenient measurement modes for wood or material humidity
- ◆ User-selectable °F or °C units
- ◆ See in all conditions with backlit display
- ◆ Low-battery indicator
- ◆ Preserve battery with automatic shutoff

## Applications

- ◆ Building inspection/restoration
- ◆ Wood products/woodworking
- ◆ Flooring
- ◆ Paper products

## Includes

Batteries

## Specifications



	Range	Resolution	Accuracy
<b>Moisture</b>	Wood: 6 to 44%	Wood: 1%	Wood: ±2%
	Material: 0.2 to 2.0%	Material: 0.1%	Material: ±0.2%
<b>Temperature</b>	32 to 122°F (0 to 50°C)	1°F/C	±1.8°F (1°C)

**Display**  
LCD

**Auto power-off**  
Unit shuts off automatically after six minutes to preserve battery life

**Dimensions (L x W x H)**  
3½" x 1½" x ¾"  
(9 x 4 x 2 cm)

**Power**  
Four 1.5V button cells (included)

Catalog number	Description
MW-20250-35	Pin-style pocket moisture meter



Contact:  
Industrial Process Measurement, Inc.  
3910 Park Avenue, Unit 7  
Edison, NJ 08820  
732-632-6400  
support@instrumentation2000.com  
<http://www.instrumentation2000.com>