

AC Line Separator

✓ **Enables user of a clamp meter to measure current on a 2-wire or 3-wire power cord to 15 Amps**

Features:

- Provides easy and safe measurement of current without the need to cut off the plug and separate the conductors
- Plugging the power connector into the Line Splitter separates the hot/live conductor from the neutral (and ground)
- Voltage check function
- Two clamp positions:
 - x1 for direct readings
 - x10 for actual reading multiplied by 10
- Dimensions: 5.25x2x1(133x51x25mm)
- Weight: 5.8 oz (164.4g)



Provides easy and safe measurement of current without the need to cut off the plug and separate the conductors

Ordering Information:

480172AC Line Separator 3-prong plug

Contact:
Industrial Process Measurement, Inc.
3910 Park Avenue, Unit 7
Edison, NJ 08820
732-632-6400
support@instrumentation2000.com
<http://www.instrumentation2000.com>

