

MD10 Non-contact Magnet Detector + Flashlight



Blue LED lights up indicating the presence of a magnetic field including AC, DC and permanent magnets without contact. The convenient built-in bright flashlight allows for viewing in dimly lit areas.

Applications:

- Test audio speakers
- Troubleshoot solenoid valves in pneumatic and hydraulic control equipment
- Test relays with coils and electrically controlled solenoid valves in vehicles and machinery

Features

- Detects the presence of magnetic field without contact (AC, DC, and permanent magnets)
- Blue LED lights up for visual magnetic field indication
- Magnetic field detection range: 63H, 98H, 401H, 810H
- Low battery indicator
- Built-in bright flashlight with On/Off button
- Compact size with pocket clip
- Dimensions: 6.25 x 0.8x 1" (159 x 21 x 25mm); Weight: 1.7oz (48g)
- Complete with two AAA batteries

Ordering

MD10..... Magnet Detector

