

## PT400 Programmable Timer



The Extech PT400 provides flexible energy-saving solutions for your day-to-day use of appliances in the home or office. It features three selectable power settings (Manual ON, Manual OFF, and Auto), ten customizable ON/OFF programs, and sixteen program combinations for individual days, weekends, week, and more. It simultaneously displays time of day (12/24 hour format), day of the week, and the currently-selected program. It also has Daylight Savings mode, randomize program function, and countdown timer. Design includes standard North American 3-prong electrical plug, side-socket connection for ease-of-use, and rechargeable backup battery that saves customized programs in the event of a power outage.



### Features

- LCD displays time, day and program function
- Program time resolution is 1 minute
- Sixteen Program combinations for individual days or Mon-Fri, Mon-Sun, Sat-Sun, Mon-Sat, Mon/Weds/Fri, Tues/Thurs/Sat, Mon/Tues/Weds, Thurs/Fri/Sat, Mon/Weds/Fri/Sun
- Easy to install and operate
- Programmable countdown function from 99 hours, 59 minutes and 59 seconds
- Random Function
- 12/24 hour mode with Daylight Savings Time function
- Rechargeable battery backup (>100 hours)
- Standard North American (Type B) 3-prong plug and front socket for easy connection

### Specifications

Switching Capacity	15A General Purpose or Resistive Load; 10A Tungsten, 1/2 HP, TV-5
Power	125V AC, 60Hz
Switch Settings	10 On/Off Programs
Switching Interval	1 minute minimum On/Off time
Random Function	Switches on randomly for 10 to 31 minutes between 6:00PM and 6:00AM
Dimensions	2.57 x 2.67 x 2.4" (65.3 x 67.8 x 61mm)
Weight	4 oz (113.4g)

### Ordering

PT400 ..... Programmable Timer

Note: Designed with a standard North American (Type B) 3-prong plug and side socket connector



UPC Code: 793950234006