

# Fluke 700PCK Pressure Calibration Kit



## Product overview: Fluke 700PCK Pressure Calibration Kit

**Description:** The Fluke 700PCK makes it possible to calibrate your pressure modules at your facility using your own precision pressure standards.

**Application:** When installed on your PC, the WindowsT-based software easily steps you through an as-found verification, a calibration adjustment, and an as-left verification. Calibration data is captured for import to your database. A 386 or better PC running Windows 3.1 or better is required, along with a precision pressure standard with an uncertainty of less than 1/4 that of the pressure module being verified.

## Ordering information



### **Fluke 700PCK**

Pressure Calibration Kit

---

Included: The kit consists of a power supply, an interface adapter, appropriate cables, and Fluke 700PC Pressure Module Calibration Software.

Warranty: One year

---

**Fluke.** *Keeping your world up and running.®*

Contact:  
Industrial Process Measurement, Inc.  
3910 Park Ave, Unit #7  
Edison, NJ 08820 USA  
(732) 632-6400  
support@instrumentation2000.com  
<https://www.instrumentation2000.com/>

©2023 Fluke Corporation.  
Specifications subject to change without notice.  
08/2023

**Modification of this document is not permitted  
without written permission from Fluke Corporation.**