

INSTRUCTIONS FOR A600FC

Description

This is a meter which has Thermometer/Humidity on one dial, it can be applied widely, in all stainless steel construction, it can provide temperature and humidity indication.

Areas of Application

Air-condition room, laboratory, computer room, sauna room, warehouse, workshop nursery, office and bedroom.

Working Condition

1. Indoor Application, static state, no wind flows.
2. NO shaking on the hanging position

Technical Data

Range -

Temperature:30/250F&C Dual Scales

Humidity:0/100%

Accuracy-

Temperature:+/-2F

Humidity:+/-6%

Notice for using and maintenance

1. The hanging position is not available if the wall with sunshine beating and vent hole of air-condition machine (bad air-flowing state). It can have correct indicating after 30 minutes.
2. It can't be poured by rain, and put in the surrounding which has corrodible gas to brass.
3. If in doubt to the indicating, put the meter in a small room without any wind flowing, 30 minutes later, adjust on the back to get the accurate indication according to the standard instrument.