

PT-99

Pocket Tachometer



The **Pocket Tach 99 (PT99)** is a digital, battery-powered portable non-contact optical tachometer, which operates up to 36 inches from a reflective target using a bright red LED light source. The ergonomic design allows safe, direct line-of-sight viewing of both the rotating target and the display at the same time, while providing a non-slip rubber surface for single hand operation. The **PT99** is the value-leader of the world-class Pocket Tach Series from Monarch.

Features

- 36 inch operating distance
- One hand operation
- LED light source
- Simple operation

Specifications

Display:	5 Digits, 5 Alphanumeric LCD
Range:	5 to 99,999 RPM
Accuracy:	0.01% or ± 1 Digit
Resolution:	Auto ranging: 0.001 to 1 RPM Fixed: 1 Digit
Operating Range:	2" to 36" (5cm to 91.44cm), $\pm 45^\circ$ from perpendicular
Memory:	Max, Min and Last
Power:	(2) "AA" 1.5Vdc batteries (60 hours)
Environmental:	5° to 40° C (40° to 105° F), 80% RH up to 31° C (88° F)
Dimensions:	6.92 x 2.4 x 1.6in (17.58 x 6.10 x 4.06cm)
Weight:	7 ounces (210 grams)

Ordering Information

Item	Description	Part No.
PT99	Tachometer with 12 inches of T-5 tape, batteries	6109-010

Contact:
Industrial Process Measurement, Inc.
3910 Park Avenue, Unit 7
Edison, NJ 08820
732-632-6400
support@instrumentation2000.com
<http://www.instrumentation2000.com>