

Model R9200

WARNING

MAX

MAX

OVER 5 mw/cm

7EBO

HOLD

 \bigcirc

REED R9200 MICROWAVE LEAKAGE DETECTOR

Microwave Leakage Detector

Instruction Manual

1-877-849-2127 | info@reedinstruments.com www.reedinstruments.com

Features

- · Detects very low levels of microwave leakage
- Audible (beep) and visual (flashing Red light alarms signals)
- Highly visible 5-digit LCD with backlight
- Built-in memory recalls maximum and minimum values, as well as last value stored
- Includes soft carrying case and batteries

Specifications

Measuring Range:	0 to 9.99 mW/cm ²
Accuracy:	±1mW/cm2
Alarm Level:	5.0db
Power Supply:	Single 9V battery
Dimensions:	190 x 60 x 42mm
Weight:	151g

Operating Instructions

- Install the 9V battery
- Press the power button
- · Press and hold the light/zero button to adjust to zero
- Take measurements
- · Press the power button to turn the instrument off

To measure the microwave leaking from microwave oven:

- Keep 2" from the door seals or the front glass of the microwave oven
- The values will display on the display
- If you press the MAX button, the maximum value will be held on the display

For service on this or any other REED product or information on other REED products, contact REED Instruments at info@reedinstruments.com

1-877-849-2127 | info@reedinstruments.com www.reedinstruments.com