

MULTIMETER COMBO KIT

TECHNICAL DATA

This REED ST-MULTIKIT Multimeter and Clamp Meter Combination Kit consists of all of the tools you will require for your Electrical needs. All items can be purchased seperatly as required

FEATURES

REED R5008 Autoranging Digital Multimeter

- Measures AC and DC voltage and current
- Temperature measurement to 760°C (1400°F)
- 0.5% basic DC accuracy
- 4,000-count resolution

REED R5040 1000A AC/DC True RMS Clamp Meter

- Measures AC and DC voltage and current, resistance, capacitance and frequency as well as temperature with the included type K thermocouple probe
- AC/DC Current Range: 500.00, 1000.0A

REED R5100 Non-Contact Voltage Detector

- Detects voltage from 100 to 600 VAC without contact
- Built-in flashlight with on/off button
- Flashing red LED indicator
- For use on 50/60 Hz circuits

REED AC-006 AC Line Splitter

- Enables clamp meter user to measure ac current on a 2-wire or 3-wire power cord to 15a
- Plugging the power connector into the line splitter separates the hot/live conductor from the neutral and ground
- Provides safe measurements of current without the need to cut off the plug and separate the conductors
- Voltage check function

REED TL-88-1 Test Leads

- Flexible silicone insulated safety test leads are heat and cold resistant
- Distinctive comfort grip test probes with stainless steel tips

REED TP-01 Type K Thermocouple Wire Probe

REED AD-1 Thermocouple Adapter

- Converts any type K temperature probe with a mini connector to standard 3/4" banana jacks

REED C-833R Carrying Case

- 11"L x 9"W x 2"D



ORDERING INFORMATION

ST-MULTIKIT.....Multimeter Combo Kit
CERTICM1.....R5040 Calibration Certificate
CERTIMM1.....R5008 Calibration Certificate

Contact:
Industrial Process Measurement, Inc.
3910 Park Avenue, Unit 7
Edison, NJ 08820
732-632-6400
support@instrumentation2000.com
<http://www.instrumentation2000.com>