

We measure it.



Smart & Wireless Thermometer*

testo 905i

Quickly and accurately measures air temperature in rooms, ducts, registers, and outlets

Fast acting temperature probe quickly tracks changes and shows trends on a graphic display

Measurement data is transmitted to the convenient and powerful **testo Smart Probes App** in your smart device

Tough, accurate, and easy-to-use

For all HVAC/R technicians and contractors



Bluetooth
+ App

testo Smart Probes App
for free download



*Operates with iOS or Android smart devices such as smart phones, tablets, etc.

The testo 905i Smart Probe is an air temperature Smart Probe that quickly and accurately measures temperature in rooms, ducts, registers, and environmental boxes/chambers. Users can remotely read the measurements from this or multiple probes by using the **testo Smart Probes App** installed on their Smart device. Smart Probes can be used individually or in combination with other Smart Probes to create measuring solutions for most HVAC/R applications. Great for setup and diagnostics of large and small HVAC/R systems. The testo 905i works on smart devices with either Android or Apple operating systems.

The **testo Smart Probes App** is a powerful and easy-to-use tool. It allows you to remotely read measurements from up to six (6) Smart Probes and easily document/report the results. Automatic calculations make it a snap! All measurement data is displayed as instrument readings, tables, or graphs. The measurements can be quickly saved as PDF or Excel files. The App creates custom reports which can be saved and/or shared by email. All your data can be stored and retrieved saving you hours of time consuming paperwork!

Technical data/accessories

testo 905i

testo 905i, Bluetooth thermometer with App,
incl. 3 AAA batteries and certificate of calibration



Order no. 0560 1905

Sensor type	Type K (NiCr-Ni)
Measuring range	-58 to 302 °F
Accuracy	±1.8 °F
Resolution	0.1 °F

General technical data

Compatibility	requires iOS 8.3 (or later) / Android 4.3 (or later) requires mobile device with Bluetooth 4.0
Storage temperature	-4 to 140 °F
Operating temperature	-4 to 122 °F
Battery type	3 AAA Batteries (incl.)
Battery life	250 hrs
Dimensions	8.7 x 1.2 x 0.9 in 3.9 in probe shaft
Warranty	2 years
Measuring Units	°F, °C

Testo Smart Probes App

The Testo **Smart Probes App** combines the power of your smart phone/tablet with the accurate measurements of your Smart Probes. The operation and display of the instruments are communicated via Bluetooth to the App on your smart phone or tablet. The **Smart Probes App** uses the measurements to create custom reports (including added photos and comments). Information and reports can be saved as files and/or sent by e-mail. For Apple iOS and Android.



VAC Smart Probe Kit: 0563 0003

Accessories

Order no.

testo VAC Smart Probe Kit for servicing ventilation and air conditioning systems. Includes: testo 405i, testo 410i, testo 605i, testo 805i. Dimensions 10.6 x 7.5 x 2.4 in	0563 0003
testo Smart Case (VAC) for the storage and transport of testo 405i, testo 410i, testo 510i, testo 605i, testo 805i and testo 905i Dimensions 10.6 x 7.5 x 2.4 in	0516 0260

Contact:
Industrial Process Measurement, Inc.
3910 Park Avenue, Unit 7
Edison, NJ 08820
732-632-6400
support@instrumentation2000.com
<http://www.instrumentation2000.com>