

8065 CamView HD Pro Ruggedized HD Camera Tester

Powerful, portable, and designed with the technician in mind

Features:

- Analog Testing for up to 8MP cameras
- 16M color, backlit 4" TFT display
- Designed to facilitate the installation and maintenance of surveillance video equipment using Standard Definition analog NTSC/PAL, HD-TVI, HD-CVI, and AHD camera systems
- Supports more than 30 Pan-Tilt-Zoom (PTZ) protocols using RS485 port
- Automatically identifies type of coding
- 12VDC/1A output
- Video Recording, Screen Shot & Frame-by-Frame or Streaming Playback
- Generate Analog NTSC/PAL and HD Video (up to 1080P 30fps) Test Patterns
- Monitor the data flow between the analog camera and the DVR system
- Check microphone/audio on the camera
- Built-in, super-bright Flashlight
- Rechargeable, long-lasting Lithium Polymer Battery
- Includes camera tester, BNC, RS485, USB, audio, power, and 12V power output cables, battery, belt clip, and tool bag with shoulder strap
- 1 year warranty



Ordering Information:

8065 CamView HD Pro Ruggedized HD Camera Tester



8065 CamView HD Pro Ruggedized HD Camera Tester

Powerful, portable, and designed with the technician in mind

Specifications

Analog and HD Video Testing	
Video Format	Auto recognizes NTSC/PAL, HD-CVI 3.0, HD-TVI 3.0, AHD 2.0
Test Pattern	Generates NTSC/PAL, HD-CVI, HD-TVI, or AHD test patterns (720P/1080P)
Signal Level	1vpp
Input/Output	Video IN BNC, Video OUT BNC
Digital Zoom	Supports 8-level portion view
Capture	Take snap shot or record video
Power Output	
Output	12V/1A power output to camera. Connector is 4mm diameter; pin is 1.6mm diameter
System	
Screen	4.0 inch TFT 800*RGB*480(WVGA) resolution, 16.7M color, backlight with adjustable brightness
Operation	Power key, 13 control keys
Language	User selectable -- English, French, Spanish, Russian, Chinese
Auto Shut-off	Disable / 5~60 minutes
Software	Supports online upgrade through USB using a Windows computer
Power	
Charger	12V/1A (5.5mm) power supply
Battery	Dedicated battery, user replaceable, 7.4V lithium-ion polymer battery, capacity 10.4Wh
Battery runtime	Approximately 5 hours
Power Saving	Auto power off; Real-time battery level indicator
Other	
Storage	8GB flash built in; use micro USB port to connect external device
LED Light	(2) 35lm LED lights
Dimensions	6.9 x 4.4 x 1.5" (175 x 113 x 37mm)
Weight	3.5lbs (1.6kg)