

9610 Plug Bug 2 GCFI Tester

Checks 3-wire electrical outlets for proper wiring and identifies 5 wiring faults

Features:

- The easy to read lights indicate the test results
- Fault charts are located on both sides of the tester so that it can easily be used on receptacles in “ground up” or “ground down” installations
- Tests for correct GFCI operation and has a test-in-progress LED indicator
- Rugged design fits easily in a tool box
- For use on standard 3-wire 110-125 VAC receptacles
- Detects correct wiring and 5 common wiring problems: Open Ground, Open Neutral, Open Hot, Hot/Ground Reverse, Hot/Neutral Reverse
- Tests for proper (GFCI) Ground Fault operation



To test, simply plug into receptacle and observe the light pattern — Fault charts are located on both sides of the tester so that it can easily be used on receptacles in “ground up” or “ground down” installations

Ordering Information:

9610 Plug Bug 2 GCFI Tester

