

# 9615 Line-Bug Telephone Line Tester

---

**4 Tri-color LEDs indicate Current, Polarity and Ringing/AC Volts**

## Features:

- Protect your expensive LAN tester by pre-testing LAN lines
- Determines if there is damaging telephone line voltage on RJ11 and RJ45 lines
- Checks LAN Lines (RJ45) wired to 568 A/B and USOC standards for damaging telephone line Voltage
- Some LAN lines have telephone voltage on previously unused pairs
- Has both RJ11 and RJ45 style plugs for testing 1-, 2-, 3-, and 4-line jacks
- Voltage is present if any LEDs light while in USOC or 568A/B switch positions
- Self powered by line voltage
- 1 year warranty



## Ordering Information:

9615 Line-Bug Telephone Line Tester