

# CTX200 Pocket Cat RJ45/Coax Tester

**Ruggedized and cushioned for toolbox use with a hidden drawer to store remote**

## Features:

- Performs a TIA568 test on CAT5/6 network cable (RJ45) with instant PASS/FAIL results — opens/shorts, reversals, split pairs, and continuity
- Includes a built-in tone generator for tracing and troubleshooting
- Complete with belt clip, RJ45 cable coax terminator, case, and 9V battery
- Tests both RJ45-CAT5/6 and coax cables with Pass/Fail results in 1 second
- Complete TIA568 test performed — Continuity, opens / shorts, reversals and split pairs
- Each pair's status is highlighted
- Tone mode for tracing and troubleshooting
- Low battery indication and Auto-off (12 seconds) battery saver
- 1 year warranty



Also available as a kit, complete with an inductive tone probe (Model CTX200PA)

## Specifications

Input Voltage/Current	Max. 5VDC, 20mA
Power	9V Battery for Toner
Dimensions	Cable Tester: 2.8 x 1.4 x 4.1" (70 x 36 x 104mm)
Weight	Cable Tester: 4oz (112g)



Confirm continuity and fault type

## Ordering Information:

CTX200 Pocket Cat RJ45/Coax Tester

