

# CTX200PA Network Cable Tester with Inductive Probe

Test and trace both RJ45-CAT5/6 and coax cables

## Features:

- Complete TIA568 test performed: Continuity, opens/shorts, reversals and split pairs
- PASS/FAIL results appear in one second
- Each pair's status is highlighted
- Tone mode allows for tracing cables with included probe
- Auto-off function conserves battery life
- Ruggedized for field use and easy to carry
- Includes BNC patch cable, CAT 6 RJ45 patch cable, BNC terminator, (2) 9V batteries, belt clip and case
- 1-year warranty



## Specifications

Input Voltage/Current	Max: 5VDC, 20mA
Power	9V Batteries for Toner and Probe
Dimensions	Cable Tester: 2.8 x 1.4 x 4.1" (70 x 36 x 104mm) Probe: 8.3 x 1.6 x 1" (212 x 40 x 27.5mm)
Weight	Cable Tester: 4oz (112g) Probe: 2.8oz (80g)

## Ordering Information:

CTX200PA Network Cable Tester with Inductive Probe

