

GSM120 Portable Carbon Monoxide (CO) Meter

Easy to use with Audible/Visual alarms

Features:

- 0 to 1000ppm range
- Max Hold records the highest reading
- Audible alarm at 35ppm increases beeping until continuous at 200ppm
- Self calibration in fresh air
- Stabilized electro-chemical gas-specific (CO) sensor
- Measuring Time Mode displays elapsed time from when the meter is powered on
- Max Hold records the highest reading
- Manually store/recall 10 readings
- Backlit LCD display
- Auto power off with disable
- Includes 9V battery, rubber holster, and carrying case
- One year warranty

Applications:

Check Carbon Monoxide (CO) levels in chimneys/flues, gas appliances (ovens, ranges, dryers), furnaces, internal combustion engines, portable generators and all coal/wood/charcoal/oil/kerosene/propane/natural gas burning devices



Specifications

	GSM120
Carbon Monoxide (CO)	0 to 1000ppm
Accuracy	±5% or ±10ppm (whichever is greater)
Resolution	1ppm
CO Alarm	Audible/Visual
CO Audible Alarm	35ppm (intermittent beep), beep speed increases up to 200ppm (continuous beep)
Memory	Manually store/recall 10 readings
Power	9V battery
Dimensions	6.3 x 2.2 x 1.6" (160 x 56 x 40mm)
Weight	6.35oz (180g)



Ordering Information:

GSM120 Portable Carbon Monoxide (CO) Meter

