

GSM130 Portable Carbon Monoxide (CO) Meter

Simultaneously displays current CO and Max CO levels

Features:

- 0 to 999ppm range
- Records maximum reading from power on (with user reset)
- 25ppm default alarm setting with user selectable settings of 30, 35, 40, 45, 50, 70, 100 and 200ppm
- Automatic calibration in clean air (0ppm) or uses 100/500ppm standard gases
- Backlit dual LCD display
- Low battery indicator
- Auto power off
- Includes (3) AAA batteries, wrist strap and pouch case
- One year warranty

Applications:

Check Carbon Monoxide (CO) levels in chimneys/flues, gas appliances (ovens, ranges, dryers), furnaces, internal combustion engines, portable generators, and all coal/wood/charcoal/oil/kerosene/propane/natural gas burning devices

Specifications

Carbon Monoxide (CO)	0 to 1000ppm
Accuracy	±5% or ±10ppm (whichever is greater)
Resolution	1ppm
CO Alarm	Audible/Visual
CO Audible Alarm	35ppm (intermittent beep), beep speed increases up to 200ppm (continuous beep)
Memory	Manually store/recall 10 readings
Power	9V battery
Dimensions	6.3 x 2.2 x 1.6" (160 x 56 x 40mm)
Weight	6.35oz (180g)



Ordering Information:

GSM130 Portable Carbon Monoxide (CO) Meter

