

MM200 Compact Multimeter

4000 count EBTN (Enhanced Black Twisted Nematic) display allows you to obtain clear readings at a maximum angle

Features:

- Measures AC/DC Voltage, Resistance, Temperature and Continuity
- Built-in NCV Detector 3 color light indication and audible beeper
- Battery strength indication on power up
- Data Hold and Auto power off with disable
- cETLus listed
- Complete with Test Leads, Temperature Probe, and (2) AAA Batteries
- Optional model complete with Certificate of Traceability to N.I.S.T.
- 1-year warranty

Applications:

- For the Professional or DIYer
- Diagnose common wiring problems; Test batteries, solar cells, wall plugs, and power outlets; Check polarity of wires in wiring installations; Measure input and output resistance of circuits (motors, transformers, resistors); Check continuity of wires, circuits

Specifications

Display counts	4000 count EBTN LCD
Basic Accuracy	±0.5%
AC/DC Voltage	600V
Resistance	20MΩ
Temperature	-40 to 572°F (-40 to 300°C)
Continuity	<30Ω
NCV Detector	3 level visual strength indication and audible beeper
Power	(2) AAA batteries
Safety Category	CAT III-600V
Dimensions	5.1 x 2.6 x 1.1" (130 x 65 x 28mm)
Weight	4.6 oz. (130g)

Ordering Information:

MM200 Compact Multimeter
MM200-NIST MM200 including Certificate of Traceability to N.I.S.T.



NIST
TRACEABLE
CALIBRATION
AVAILABLE