

UEI CD100A

TEST INSTRUMENTS™

Combustible Gas Leak Detector

FIND COMBUSTIBLE GAS LEAKS QUICKLY!

- Easy one hand operation
- Simple adjustable tic rate
- Long 18" gooseneck
- Tip light in sensor cover illuminates the area of the leak
- Headphone jack



CD100A • Combustible Gas Leak Detector

The CD100A is the perfect serviceman's tool designed to detect combustible gas leaks in residential and small commercial applications. Semiconductor sensor responds instantaneously to all combustible gases. The easily adjusted, steady tic rate can be used in tight quarters where others might not fit.

The CD100A has the following features:

- Simple adjustable tic rate
- Easy one hand operation
- Long 18" gooseneck
- Tip light in sensor cover illuminates the area of the leak
- Sensor provides accurate detection
- Audio and visual tic rate
- Headphone jack
- One year limited warranty

Replacement Parts:

Sensor.....RS1000
Sensor Cap.....RS1010

Optional Accessories:

HeadphonesHE1000
Hard Carrying Case.....AC501

Specifications

Sensitivity	50 ppm
Tic adjustment	Fully adjustable thumbwheel
Tic indication	Flashing LED
Battery	9 volt alkaline, 5 hours typical use
Sensor	Solid state semiconductor
Dimensions	8" x 4" x 1-1/2"
Weight	15 oz.



Contact:
Industrial Process Measurement, Inc.
3910 Park Avenue, Unit 7
Edison, NJ 08820
732-632-6400
support@instrumentation2000.com
<http://www.instrumentation2000.com>

UEi
TEST INSTRUMENTS™

